



Ultra Carbon Fiber model shown

## Steering Wheel Installation Instructions

Kit Contents:

1x Steering Wheel

6x M6x25 Hex Socket Bolt

1x Horn Wiring (not used)

Remove cover/card holder from factory steering wheel.

1



Loosen and remove nut from steering column spindle.  
Retain Nut.  
Remove steering wheel.

2



# Steering Wheel Installation Instructions

3

Place steering hub adapter onto steering column spindle. Using nut from Step 3, tighten steering hub adapter.



4

Remove horn switch assembly from MadJax steering wheel and press onto steering hub adapter, aligning the grooves with the holes in the adapter.



5

Press steering wheel onto horn switch assembly. Check hole alignment.



6

Attach trim ring and steering wheel to steering hub adapter using six included hex socket bolts. Tighten bolts.

