

DO NOT OVERTIGHTEN. Cut wire to the necessary length for your installation, strip the insulation from the ends of the wires and attach the supplied crimp terminals using an approriate terminal crimper.



Run the wires to the battery terminal and keyswitch locations. Once the runs are complete, attach the wires to the appropriate terminal on the meter, paying special attention to the terminal markings.

NOTE: In order to ensure proper function of your MadJax Charge Meter, terminals 1 and 2 are intended to be conntected across the ENTIRE 36V or 48V (depending on model) battery pack.